

# Recommended Cleaning & Care

BUZIL-WERK Wagner GmbH & Co. KG

## WINDOW GLASS



There are different types of window glass:

- › **Tempered safety glass:** Tempered safety glass is thermally or chemically pre-stressed glass. The pre-stressing makes the glass significantly more resistant to bending loads and temperature-related stresses.
- › **Laminated glass:** Laminated glass consists of alternating layers of glass and plastic foil. It is designed in such a way that, in the event of breakage, glass splinters or shards remain adhered to the film. At a thickness of approximately 25 mm, safety glass is also referred to as “bulletproof glass”, and among other purposes is used for shop windows and display cases.
- › **Glass with self-cleaning properties** is available in various designs. One option is for the glass to have a special coating on the outside. This releases organic contamination when exposed to UV light. The hydrophilic glass surface causes (rain)water to distribute and form a thin film on the pane, and then to rinse away the dissolved dirt.

### CLEANING

#### DEEP AND INTENSIVE CLEANING

	Dirt	Treatment	Cleaning device
Pick up loose dirt.	<b>HEAVIER DIRT THAT IS ALKALINE-SOLUBLE</b> like protein, insect soiling, oil and grease can be removed by intensive cleaning using Buz® Windowmaster G 525 or Planta® View P 318	Apply the cleaning solution evenly onto the surface using a window wiper.	
		Wipe off the dirt solution using a window squeegee.	
		Clean the window and edges of the glass dry, using chamois leather.	

# Recommended Cleaning & Care

BUZIL-WERK Wagner GmbH & Co. KG

## CONTINUED: CLEANING WINDOW GLASS

### SPECIAL CLEANING

	Dirt	Treatment	Cleaning device
Pick up loose dirt.	<b>ADHESIVE RESIDUE</b>	Spray the product onto a cloth or hand pad and remove the adhesive residue from the affected areas.	
	can be cleaned off using Buz® Point G 502.	Rinse with water after cleaning.	