

# Recommended Cleaning & Care

BUZIL-WERK Wagner GmbH & Co. KG

## POLYOLEFIN FLOOR COVERINGS



Polyolefin coverings consist of various types of plastic, often polyethylene or polypropylene. Depending on the manufacturer, these coverings may be provided with a polyurethane coating which is applied in the factory by the manufacturer. Generally, these coverings are not sensitive to acids. The coverings are also sensitive to solvents, high alkalinity of pH-value 13 or above, grease, oil and shoe polish. This dirt may permeate into the covering, and is very difficult to remove.

### CLEANING

#### DEEP CLEANING

	Dirt	Treatment	Cleaning device
Pick up loose dirt, and remove mortar, plaster residue, and colour stains manually using a scraper.	<b>RESIDUE FROM CARE PRODUCTS</b>  in the form of coatings and care products can be removed using Corridor® Unic Ultra S 707, Corridor® Power Stripper S 708 or Planta® Multi Stripper P 321.	Apply the cleaning solution evenly over the floor, and leave it to work for approximately 10 to 15 minutes. <i>PLEASE NOTE: Do not allow the cleaning solution to dry.</i>	
		Deep clean the covering using a single-disc machine and a red/blue pad.	
		Pick up the loosened dirt using a wet vacuum cleaner, and rinse with water.	

#### INTENSIVE CLEANING

	Dirt	Treatment	Cleaning device
Pick up loose dirt, and remove any mortar, plaster residue, and colour stains manually using a scraper.	<b>HEAVIER DIRT THAT IS ALKALINE-SOLUBLE</b>  like protein, oil and grease or foodstuff residue e.g. coffee, red wine etc. can be removed by intensive cleaning using Corridor® PUR Clean S 766.	Apply the cleaning solution evenly over the floor, and leave it to work for a short time.	
		Clean the covering using a single-disc machine and a red pad.	
		Pick up the loosened dirt using a wet vacuum cleaner, and rinse with water.	

# Recommended Cleaning & Care

BUZIL-WERK Wagner GmbH & Co. KG

## CONTINUED: CLEANING POLYOLEFIN FLOORS COVERINGS

### DAILY ROUTINE CLEANING

	Dirt	Treatment	Cleaning device
Microfibre cloths or pads must always be used in order to achieve a satisfactory cleaning result.	<b>ORGANIC/INORGANIC CONTAMINATION</b>  like protein, oil and grease or foodstuff residue e.g. coffee, red wine etc. Corridor® PUR Clean S 766 or products with a care element, such as the Corridor® Daily S 780, Corridor Cibreeze S790 with odour blocker and Planta® Cleen P315 wipe care products are well-suited to daily routine cleaning.	Manual floor treatment	
	<b>INFECTION PREVENTION</b>	The Buzil Budenat® portfolio surface disinfectant is ideal for defined areas (see Disinfectants).	

## CARE

### INITIAL TREATMENT

An additional coat of dispersion or emulsion is not advised. Polyolefin coverings feature their own gloss, which also cannot be increased through the use of additional coatings. Instead, following coating, unevenness in the sublevel is more visible as a result of the flooring's own gloss and its colour.

### COATING REPAIR

Care	Treatment	Cleaning device
Pick up loose dirt, and remove any mortar, plaster residue, and colour stains manually using a scraper.	Spray the Maradin HC 43 intensive cleaner onto the surface at the recommended dosage, working on a section at a time.	
	Clean the area using a single-disc machine and a red pad. <i>Replace the pad regularly when doing so.</i>	
	Then wipe the floor covering with water; further rinsing and neutralisation are not necessary.	
	Spray Corridor® Spray S 770 (undiluted) onto the clean surface, working on a section at a time.	
	Use a high-speed machine and a polishing pad to achieve a high gloss floor finish.	

The products named above are examples of usable buzil products. Always test the compatibility of the material to be treated with the cleaning or care product in an inobtrusive area first. Always use our products in accordance with the content of the product information. All datasheets are available online at [www.buzil.de/en](http://www.buzil.de/en). Our Application Technology team will be very happy to help if you have any questions, and can be reached by phone on +49 8331 930-6, fax on +49 8331 930-883, or email at [awt@buzil.de](mailto:awt@buzil.de).