

Recommended Cleaning & Care

BUZIL-WERK Wagner GmbH & Co. KG

CLINKER AND TERRACOTTA FLOOR COVERINGS, UNGLAZED

Clinker and terracotta floor coverings are stoneware slabs which are fired up to sintering point (at approximately 1350°C). These ceramic coverings are processed glazed and unglazed. Most clinker and terracotta flooring is resistant to chemicals. Phosphorus-based cleaning agents (with a pH-value lower than 3) may cause efflorescence. Oils and greases may cause stains in porous coverings.



CLEANING

DEEP CLEANING

	Dirt	Treatment	Cleaning device
Pick up loose dirt, and remove any mort- ar, plaster residue, and colour stains manually using a scraper.	e.g. cement residue in areas with high water hardness, as well as after renovations can be removed using Bucasan® Clear G 463.	Pre-wet the floor covering (important for protecting the cement joints!), and apply the cleaning solution.	*
		Deep clean using a single-disc machine and a white brush or white pad.	
		Pick up the loosened dirt using a wet vacuum cleaner, and rinse with water.	
	RESIDUE FROM CARE PRODUCTS in the form of coatings and care products can be removed using Corridor® Unic Ultra S 707, Corridor® Power Stripper S 708 or Planta® Multi Stripper P 321.	Apply the cleaning solution evenly over the floor, and leave it to work for approximately 10 to 15 minutes. PLEASE NOTE: Do not allow the cleaning solution to dry.	
		Deep clean the covering using a sing- le-disc machine and a blue pad/white brush.	
		Pick up the loosened dirt using a wet vacuum cleaner, and rinse with water.	

1



Recommended Cleaning & Care

BUZIL-WERK Wagner GmbH & Co. KG

CONTINUED: CLEANING CLINKER AND TERRACOTTA FLOORING

INTENSIVE CLEANING

Pick up loose dirt, and remove any mort- ar, plaster residue, and colour stains manually using a scraper.	Dirt	Treatment	Cleaning device
	HEAVIER DIRT THAT IS ALKALINE-SOLUBLE like protein, oil and grease or foodstuff residue e.g. coffee, red wine etc. can be removed by intensive cleaning using Indumaster® Universal IR 55.	Apply the cleaning solution evenly over the floor, and leave it to work for a short time.	†
		Clean using a single-disc machine and a red pad.	
		Pick up the loosened dirt using a wet vacuum cleaner, and rinse with water.	

DAILY ROUTINE CLEANING

	Dirt	Treatment	Cleaning device
Microfibre cloths or pads must always be used in order to achieve a satisfactory cleaning result.	ORGANIC/INORGANIC CONTAMINATION like protein, oil and grease or foodstuff residue e.g. coffee, red wine etc. Soap-based products with significant care elements such as Buz® Soap G 240, or water-soluble-polymer-based Planta® Cleen P 315 and Corridor® Daily S 780 wipe care products are well-suited to daily routine cleaning. The ultra-moistening Roca Wipe R 300 floor maintenance cleaner is particularly well-suited if the floor covering is impregnated or highly polished.	Manual floor treatment	

CARE

PRIMING

INPINO		
Care	Treatment	Cleaning device
The use of Corridor® Basic S 720 protects the floor covering against deep-pore contamination and mechanical damage in the long-term. PLEASE NOTE: Corridor® Basic S 720, applied just once, will not be dissolved during later intensive or deep cleaning, even if strong	Apply the first layer of pore filler diluted 1:1 with water, and then evenly apply an additional 1-2 thin undiluted layers, leaving each layer to dry completely in turn.	
cleaning agents are used; as a result, this product functions as a long- term primer.	Polishing is not required.	



Recommended Cleaning & Care

BUZIL-WERK Wagner GmbH & Co. KG

CONTINUED: CARING FOR CLINKER AND TERRACOTTA FLOORING

INITIAL TREATMENT

Care	Treatment	Cleaning device
These floor coverings can be subject to initial treatment with the Roca Dispers R 200 coating product.	3	
	Polishing is not required.	
Soap-based wipe care products such as Buz® Soap G 240 are also used as an alternative method of providing the floor with a sufficient protective film.	Apply the cleaning solution onto the floor covering and leave to dry.	
	Then, polish using a soft natural brush or appropriate pad.	

IMPREGNATION

Care	Treatment	Cleaning device
To significantly reduce the dirt absorption capacity of the floor covering, it is impregnated with Roca Pregno R 100.	Use a flat mop to apply Roca Pregno R 100 undiluted, in thin layers.	
Detailed information on impregnation using the Roca system is available in our "Impregnation" cleaning recommendation. PLEASE NOTE: Impregnation is only possible on non-primed coverings that have also not been subject to initial treatment.	After a drying time of approximately 30 minutes, remove any excess product that has not yet permeated using a squeegee, and then polish the covering with a soft, absorbent pad (e.g. Coral rosa from Dolly).	